



## **SIM7080** Series\_Linux\_Application Note

Version:1.00

Release Date:Feb 26, 2020

# About Document

## Document Information

Document	
Title	SIM7080 Series_Linux_Application Note
Version	1.00
Document Type	User Guide
Document Status	Released/Confidential

## Revision History

Revision	Date	Owner	Status / Comments
1.00	Feb 26, 2020	Dong.liu	First Release

## Related Documents

[1] SIM7080 Series AT Command Manual V1.02

### This document applies to the following products:

Name	Type	Size (mm)	Comments
SIM7080G	CAT-M/NB	17.6*15.7 *2.3	N/A
SIM7070G/SIM7070E	CAT-M/NB/EGPRS	24*24*2.4	N/A
SIM7070G-NG	NB/EGPRS	24*24*2.4	N/A
SIM7090G	CAT-M/NB	14.8*12.8*2.0	N/A

## Copyrights

This document contains proprietary technical information which is the property of SIMCom Wireless Solutions Co.,Ltd. Copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

# Contents

<b>About Document .....</b>	<b>2</b>
Document Information.....	2
Revision History.....	2
Related Documents.....	2
Copyrights .....	2
<b>Contents.....</b>	<b>3</b>
<b>1 Purpose of this document .....</b>	<b>4</b>
<b>2 USB Introduction .....</b>	<b>4</b>
<b>3 Install USB Serial Driver .....</b>	<b>4</b>
3.1 Precondition .....	4
3.2 Add VID and PID .....	5
3.3 Kernel debug message .....	5
<b>4 Verification.....</b>	<b>6</b>
<b>5 PPPD Call.....</b>	<b>6</b>
5.1 Configure PPP protocol .....	6
5.2 Configure PPPD .....	7
5.2.1 Create option file.....	7
5.2.2 Create chat file .....	7
5.3 PPPD call.....	8
<b>Contact.....</b>	<b>11</b>

# 1 Purpose of this document

This document will introduce how to install USB driver on Linux and how to run PPP application on SIM7070\7080\7090 series of module. Developers could understand and develop application quickly and efficiently based on this document.

## 2 USB Introduction

The USB (Universal Serial BUS) protocol states that all USB devices have a VID (Vendor ID) and a PID (Product ID). The VID is applied by the supplier to the USB-IF (Implementers Forum, Applicant Forum). The VID of each supplier is unique and the PID is at the discretion of the supplier. The host uses VID and PID to identify different USB devices. Depending on them (and the version number of the device), the corresponding driver can be loaded or installed on the device. Both VID and PID are two bytes in length.

For SIM7070/SIM7080/SIM7090 series of module, VID=0x1E0E, and PID=0x9205.

As an USB device, SIM7070/SIM7080/SIM7090 USB is enumerated as listed below.

Interface number	Endpoint Type	Function
0	USB serial	Diagnostic Interface
1	USB serial	GPS NMEA Interface
2	USB serial	AT port Interface
3	USB serial	Modem port Interface
4	USB ECM	ECM Interface

## 3 Install USB Serial Driver

Before install USB driver, please make sure module has been powered up and connected with Linux, developer can check the hardware connection by *lsusb* or *dmesg* log.

### 3.1 Precondition

Configure Linux kernel as following to support USB serial features.

`CONFIG_USB_SERIAL=y`

`CONFIG_USB_SERIAL_OPTION=y`

## 3.2 Add VID and PID

Find and modify source code file **option.c** in kernel. (Usually, it is located in the path: **drivers/usb/serial/option.c**)

*If kernel version is V3.2 or newer*

```
#define SIMCOM_SIM7080_VID          0x1E0E
#define SIMCOM_SIM7080_PID          0x9205

static const struct option_blacklist_info simcom_SIM7080_blacklist = {
};

Add into option_ids list
... ..

{ USB_DEVICE(SIMCOM_SIM7080_VID, SIMCOM_SIM7080_PID),
  .driver_info = (kernel_ulong_t)& simcom_SIM7080_blacklist t
},

... ..
```

*If kernel version is below V3.2*

```
#define SIMCOM_SIM7080_VID          0x1E0E
#define SIMCOM_SIM7080_PID          0x9205

Add into option_ids list

static const struct usb_device_id option_ids[] = {

{ USB_DEVICE(SIMCOM_SIM7080_VID, SIMCOM_SIM7080_PID) },

};

static int option_probe(struct usb_serial *serial,
const struct usb_device_id *id)  {
.....
if (serial->dev->descriptor.idVendor == SIMCOM_SIM7080_VID &&
    serial->dev->descriptor.idProduct == SIMCOM_SIM7080_PID)
return -ENODEV;
.....
}
```

## 3.3 Kernel debug message

If USB serial driver is installed successfully, kernel will print below message automatically after

module was re-started. And from this message, we could confirm if **dev/ttyUSB#** was enumerated successfully or not.

```
cdc_ether 1-2:1.4 eth1: register 'cdc_ether' at usb-0000:00:14.0-2, CDC Ethernet Device, 00:a0:c6:cf:2a:f0
...
option 1-2:1.0: GSM modem (1-port) converter detected
usb 1-2: GSM modem (1-port) converter now attached to ttyUSB0
option 1-2:1.1: GSM modem (1-port) converter detected
usb 1-2: GSM modem (1-port) converter now attached to ttyUSB1
option 1-2:1.2: GSM modem (1-port) converter detected
usb 1-2: GSM modem (1-port) converter now attached to ttyUSB2
option 1-2:1.3: GSM modem (1-port) converter detected
usb 1-2: GSM modem (1-port) converter now attached to ttyUSB3
```

## 4 Verification

Now developer can verify if driver has been installed.

- 1) Connect physical USB interface of module and power on it.
- 2) Open Linux terminal and type the shell command “**dmesg**” to view kernel print information.

```
83805.539479] option 1-1:1.0: GSM modem (1-port) converter detected
83805.612641] usb 1-1: GSM modem (1-port) converter now attached to ttyUSB0
83805.658475] option 1-1:1.1: GSM modem (1-port) converter detected
83805.659148] usb 1-1: GSM modem (1-port) converter now attached to ttyUSB1
83805.678016] option 1-1:1.2: GSM modem (1-port) converter detected
83805.696007] usb 1-1: GSM modem (1-port) converter now attached to ttyUSB2
83805.696145] option 1-1:1.3: GSM modem (1-port) converter detected
83805.696612] usb 1-1: GSM modem (1-port) converter now attached to ttyUSB4
83805.812814] cdc_ether 1-1:1.4 eth0: register 'cdc_ether' at usb-0000:02:03.0-1, CDC Ethernet Device, 00:a0:c6:cf:2a:f0
```

- 3) List the ttyUSBx devices by “**ls -l /dev/ttyUSB\***”.

The following files have been created in the /dev/ directory.

```
root@ubuntu:/etc/ppp# ls -l /dev/ttyUSB*
crw-rw---- 1 root dialout 188, 0 Nov 19 17:38 /dev/ttyUSB0
crw-rw---- 1 root dialout 188, 1 Nov 19 17:38 /dev/ttyUSB1
crw-rw---- 1 root dialout 188, 2 Nov 19 17:45 /dev/ttyUSB2
crw-rw---- 1 root dialout 188, 4 Nov 19 17:38 /dev/ttyUSB4
```

This information indicates device driver is installed successfully and the module was recognized by the PC device.

## 5 PPPD Call

### 5.1 Configure PPP protocol

Since PPP dialing requires the chat and PPPD command, you need to download the PPP protocol.

Confirm that the following files already exists in Linux file system. If not, you need to apt-get install PPP.

```
/etc/ppp/chap-secrets  
/etc/ppp/pap-secrets  
/etc/ppp/ip-up  
/etc/ppp/ip-down  
/etc/ppp/peer/
```

## 5.2 Configure PPPD

Create 2 files under the file system /etc/ppp directory as follows: sim7080option and sim7080-chat.dat

### 5.2.1 Create option file

Create the new file for PPPD tty option **/etc/ppp/peer/sim7080option**.

**/dev/ttyUSB3** will be changeable according your module ports.

The sim7080option file contents are as follows:

```
#/etc/ppp/peers/ sim7080option  
# This is pppd script for China Mobile, used SIMCOM Module  
/dev/ttyUSB3  
#/dev/pts/11  
115200  
nocrtscts  
noauth  
connect '/usr/sbin/chat -v -s -f /etc/ppp/sim7080-chat.dat'  
disconnect '/usr/sbin/chat -e -v "" +++ath'  
debug  
ipcp-accept-local  
ipcp-accept-remote  
usepeerdns  
defaultroute  
lcp-echo-failure 3  
lcp-echo-interval 2  
#asyncmap fffffff  
#idle 480
```

### 5.2.2 Create chat file

Create the chat file for PPPD chat **/etc/ppp/sim7080-chat.dat**.

The Chat program is used to establish a connection between the local PPPD and the remote PPPD program.



AT+CGDCONT sets the APN of the module, ibox.tim.it will be changeable according your modem APN.

The sim7080-chat.dat file contents are as follows:

```
#/etc/ppp/sim7080-chat.dat
ABORT          'NO CARRIER'
ABORT          'NO DIALTONE'
ABORT          'ERROR'
ABORT          'NO ANSWER'
ABORT          'BUSY'
TIMEOUT        120
"              AT
OK             ATE1
OK             AT+CGDCONT=1,"IPV4V6","ibox.tim.it"
OK             ATD*99#
CONNECT       "
```

### 5.3 PPPD call

1. Before dial-up, please shut down the eth0 .
2. Script file gives execute permission and executes with root privileges
3. Dial by the following command: `pppd call sim7080option`
4. Execution results, you can view file /tmp/ppp.log.

```
root@ubuntu:/# pppd call sim7080option debug logfile /tmp/ppp.log
```

```
abort on (NO CARRIER)
```

```
abort on (NO DIALTONE)
```

```
abort on (ERROR)
```

```
abort on (NO ANSWER)
```

```
abort on (BUSY)
```

```
timeout set to 120 seconds
```

```
send (AT^M)
```

```
expect (OK)
```

```
^M
```

```
OK
```

```
-- got it
```

```
send (ATE1^M)
```

```
expect (OK)
```

```
^M
```

```
^M
```

```
OK
```

```
-- got it
```



```
send (AT+CGDCONT=1,"IPV4V6","ibox.tim.it"^M)
```

```
expect (OK)
```

```
^M
```

```
AT+CGDCONT=1,"IPV4V6","ibox.tim.it"^M^M
```

```
OK
```

```
-- got it
```

```
send (ATD*99#^M)
```

```
expect (CONNECT)
```

```
^M
```

```
ATD*99#^M^M
```

```
CONNECT
```

```
-- got it
```

```
send (^M)
```

```
Script /usr/sbin/chat -v -s -f /etc/ppp/sim7000-chat.dat finished (pid 12254), status = 0x0
```

```
Serial connection established.
```

```
using channel 5
```

```
Using interface ppp0
```

```
Connect: ppp0 <--> /dev/ttyUSB4
```

```
sent [LCP ConfReq id=0x1 <asynctest 0x0> <magic 0xfa37b19e> <pcomp> <accomp>]
```

```
rcvd [LCP ConfReq id=0x0 <asynctest 0x0> <auth chap MD5> <magic 0xc5bc7416> <pcomp> <accomp>]
```

```
sent [LCP ConfNak id=0x0 <auth pap>]
```

```
rcvd [LCP ConfAck id=0x1 <asynctest 0x0> <magic 0xfa37b19e> <pcomp> <accomp>]
```

```
rcvd [LCP ConfReq id=0x1 <asynctest 0x0> <auth pap> <magic 0xc5bc7416> <pcomp> <accomp>]
```

```
sent [LCP ConfAck id=0x1 <asynctest 0x0> <auth pap> <magic 0xc5bc7416> <pcomp> <accomp>]
```

```
sent [LCP EchoReq id=0x0 magic=0xfa37b19e]
```

```
sent [PAP AuthReq id=0x1 user="ubuntu" password=<hidden>]
```

```
rcvd [LCP DiscReq id=0x2 magic=0xc5bc7416]
```

```
rcvd [LCP EchoRep id=0x0 magic=0xc5bc7416 fa 37 b1 9e]
```

```
rcvd [PAP AuthAck id=0x1 ""]
```

```
PAP authentication succeeded
```

```
sent [CCP ConfReq id=0x1 <deflate 15> <deflate(old#) 15> <bsd v1 15>]
```

```
sent [IPCP ConfReq id=0x1 <compress VJ 0f 01> <addr 0.0.0.0> <ms-dns1 0.0.0.0> <ms-dns2 0.0.0.0>]
```

```
rcvd [LCP ProtRej id=0x3 80 fd 01 01 00 0f 1a 04 78 00 18 04 78 00 15 03 2f]
```

```
Protocol-Reject for 'Compression Control Protocol' (0x80fd) received
```

```
sent [IPCP ConfReq id=0x1 <compress VJ 0f 01> <addr 0.0.0.0> <ms-dns1 0.0.0.0> <ms-dns2 0.0.0.0>]
```

```
rcvd [IPCP ConfReq id=0x0]
```

```
sent [IPCP ConfNak id=0x0 <addr 0.0.0.0>]
```

```
rcvd [IPCP ConfRej id=0x1 <compress VJ 0f 01>]
```

```
sent [IPCP ConfReq id=0x2 <addr 0.0.0.0> <ms-dns1 0.0.0.0> <ms-dns2 0.0.0.0>]
```

```
rcvd [IPCP ConfReq id=0x1]
```

```
sent [IPCP ConfAck id=0x1]
```

```
rcvd [IPCP ConfNak id=0x2 <addr 100.70.197.238> <ms-dns1 211.136.17.107> <ms-dns2 211.136.20.203>]
```

```
sent [IPCP ConfReq id=0x3 <addr 100.70.197.238> <ms-dns1 211.136.17.107> <ms-dns2 211.136.20.203>]
rcvd [IPCP ConfAck id=0x3 <addr 100.70.197.238> <ms-dns1 211.136.17.107> <ms-dns2 211.136.20.203>]
Could not determine remote IP address: defaulting to 10.64.64.64
not replacing default route to ens33 [172.21.254.254]
local IP address 100.70.197.238
remote IP address 10.64.64.64
primary DNS address 211.136.17.107
secondary DNS address 211.136.20.203
Script /etc/ppp/ip-up started (pid 12270)
Script /etc/ppp/ip-up finished (pid 12270), status = 0x0
rcvd [IPCP ConfReq id=0x2]
Connect time 0.1 minutes.
Sent 0 bytes, received 14 bytes.
Script /etc/ppp/ip-down started (pid 12315)
sent [IPCP ConfReq id=0x4 <compress VJ 0f 01> <addr 100.70.197.238> <ms-dns1 0.0.0.0> <ms-dns2 0.0.0.0>]
sent [IPCP ConfNak id=0x2 <addr 0.0.0.0>]
rcvd [IPCP ConfRej id=0x1 <compress VJ 0f 01>]
rcvd [IPCP ConfRej id=0x4 <compress VJ 0f 01>]
sent [IPCP ConfReq id=0x5 <addr 100.70.197.238> <ms-dns1 0.0.0.0> <ms-dns2 0.0.0.0>]
rcvd [IPCP ConfReq id=0x3]
sent [IPCP ConfAck id=0x3]
rcvd [IPCP ConfNak id=0x5 <ms-dns1 211.136.17.107> <ms-dns2 211.136.20.203>]
sent [IPCP ConfReq id=0x6 <addr 100.70.197.238> <ms-dns1 211.136.17.107> <ms-dns2 211.136.20.203>]
rcvd [IPCP ConfAck id=0x6 <addr 100.70.197.238> <ms-dns1 211.136.17.107> <ms-dns2 211.136.20.203>]
Could not determine remote IP address: defaulting to 10.64.64.64
not replacing default route to ens33 [172.21.254.254]
local IP address 100.70.197.238
remote IP address 10.64.64.64
primary DNS address 211.136.17.107
secondary DNS address 211.136.20.203
Script /etc/ppp/ip-down finished (pid 12315), status = 0x0
Script /etc/ppp/ip-up started (pid 12361)
Script /etc/ppp/ip-up finished (pid 12361), status = 0x0
sent [LCP EchoReq id=0x1 magic=0xfa37b19e]
rcvd [LCP EchoRep id=0x1 magic=0xc5bc7416 fa 37 b1 9e]
sent [LCP EchoReq id=0x2 magic=0xfa37b19e]
rcvd [LCP EchoRep id=0x2 magic=0xc5bc7416 fa 37 b1 9e]
```

## Contact

### **SIMCom Wireless Solutions Co.,Ltd**

Address: Building B, No.633 Jinzhong Road, Changning District, Shanghai P.R.China 200335

Tel: +86-21-31575126

Support: support@simcom.com